

Clostridium difficile - Surface - Plastic					
Time (min)	CFU	Log	SD	Log Reduction	99.97% Reduction in 30 Seconds Non- Detectable in 2 Minutes
0	44,652,000	7.65	0.3	-	
0.5	12,882	4.11	0.2	4.25	
1	1,738	3.24	0	7.49	
2	<10	0.00	0	7.65	
4	0	0.00	0	7.65	

Clostridium difficile - Surface - Stainless Steel					
Time (min)	CFU	Log	SD	Log Reduction	99.996% Reduction in 30 Seconds Non- Detectable in 2 Minutes
0	44,652,000	7.65	0.3	-	
0.5	1,698	3.22	0.2	4.33	
1	481	2.68	0	7.11	
2	<10	0.00	0	7.65	
4	0	0.00	0	7.65	

The implementation of ADB is not intended to take the place of reasonable pathogen transmission safety precautions. Please understand and comply with local, state, and federal guidelines and public health laws, and be aware of Official guidance published by the Centers for Disease Control and Prevention (CDC), including but not limited to social distancing, hand hygiene, cough etiquette, and the use of face masks.